
City & State of Downlink Location Washington DC <u>Diagram: 01/25/02</u>

BLM Office BLM Headquarters Office L St

Diagram Contact Mr. Vince Saulino

Diagram Code: BLMHQLstreet



The PTT switch is selected on the AB Box.

BLM Headquarters Office L Street Washington DC